

OUTSIDE MIRROR DIMMING INSTRUCTIONS

(REFER TO MAIN MIRROR KIT INSTRUCTIONS, WHERE APPLICABLE)

Description:

These leads will allow the ability to add control of the outside rearview mirror auto-dim function to the 9002-9515 and 9002-9516 mirror.

Step 1): Located on the bottom side of the Brandmotion 16 pin mirror connector is a rectangular white tab. This tab must first be released (see figure 1). A small flathead watch repair screw driver works best. The tab will only lift about 1/10th of an inch.

Figure 1



Insert the orange lead into 16 pin cavity 5 and insert the white lead into 16 pin cavity 16

Step 2) Follow the supplied chart to connect the above leads to the vehicle harness.

Note: Due to the large variations of vehicle models and years you must follow the pin locations on the OE mirror connector and is the reason why wire colors were not supplied.

Brandmotion	Ford Mirror Connector			Description
	7 Pin	10 Pin	16 Pin	
Orange	4	8	11	Mirror Feed +
White	5	7	15	Mirror Feed -

Step 3) Install mirror and camera as per instructions (supplied separately).

Note: We strive to provide accurate and up-to-date installation instructions. For the latest instructions please visit www.brandmotion.com.