



Display Monitor Windshield Mount for 2007-current Sprinter vans (Kit # 5000-SPMT)

NOTE: This mount is utilized to replace the current rear view mirror with the ability to mount a camera display monitor (monitor must have vertical mounting slot on back like the Brandmotion FLTW-7670 and FLTW-7640).

Please read thoroughly before starting installation and check that kit contents are complete.



Safety Precautions:

- Work in well ventilated area that is clear of obstructions.
- Secure vehicle with tire chucks in both front and rear of tires.
- Turn vehicle accessories OFF and ensure ignition key is in OFF position.
- Wear safety goggles and snug fitting clothes.
- Use tools only for their intended purpose and which are in good repair.
- Only perform this task if confidence, skill, and physical ability permit.

NOTE: We strive to provide accurate and up-to-date installation instructions. For the latest full color instructions, as well as an installation video, please visit <u>www.brandmotion.com</u>

INSTALLATION INSTRUCTIONS



INSTALLATION:

- Loosen the screw that secures the existing mirror to the Sprinter mount, and remove the existing mirror from the mount on windshield per manufacturer's directions. Do NOT use a twisting motion to remove the mirror from the Sprinter mount or you risk damage to the windshield, including cracking your windshield. If you are unable to remove the existing mirror from the D-tab/wedge mount without force, we recommend contacting a local auto glass installer for assistance.
- 2. Connect the 5000-SPMT to the vertical mounting slot on the display monitor. (Brandmotion recommends using our FLTW-7640 and FLTW-7670.)
- Slide the 5000-SPMT onto the Sprinter mount. Tighten the screw using the supplied Allen wrench to secure the 5000-SPMT in place. Torque for the mirror screw that attaches to the windshield tab is 1.8 Nm (16 lb-in) and cannot exceed 2.2 Nm (19.5 lb-in).
- 4. Connect the display monitor to camera and power per the manufacturer's directions.