

## **Chevrolet/ GMC Mylink Display Radio Camera Interface Harness (Kit # 9002-2760)**

**Please read thoroughly before starting installation and check that kit contents are complete.**

### **Items Included in the Kit:**

44 pin Interface Harness  
LCD Y Harness  
Interface box  
These Instructions

### **Tools & Supplies Needed:**

Plastic Trim Removal Tool  
7mm Socket  
Vehicle service manual (If needed)  
Zip ties

### **Safety Precautions:**

- Work in well ventilated area that is clear of obstructions.
- Secure vehicle with tire chucks in both front and rear of tires.
- Turn vehicle accessories OFF and ensure ignition key is in OFF position.
- Wear safety goggles and snug fitting clothes.
- Use tools only for their intended purpose and which are in good repair.
- Only perform this task if confidence, skill, and physical ability permit.

**NOTE: We strive to provide accurate and up-to-date installation instructions. For the latest full color instructions, as well as an installation video, please visit [www.brandmotion.com](http://www.brandmotion.com)**

1. Remove sun visor over display screen, by pulling up from the front to unsnap clips.

2. Remove console front side trim, by using plastic panel removal tool to release clips. Lift up to remove trim off console.



3. Remove screen trim/ radio control panel by using a panel tool to unsnap clips from the sides. Unplug connector and set aside.
4. Remove (4) 7mm screws from under the console trim. Remove (4) 7mm screws from under the screen trim. Remove (4) 7mm from around the screen in the dash.



## INSTALLATION INSTRUCTIONS

5. Remove the screen, unplug the connectors and set aside.
6. In the lower part of the dash opening above the cd slot there is a plastic "bracket" that has to be removed.
7. Remove the pocket piece around the cd slot by pulling it towards you, (it is a little snug). Disconnect the power point plug from behind the pocket.
8. Remove (4) 7mm screws from the cd/radio cage from behind the pocket opening. Remove radio by do not unplug harness.



9. Unplug the 44 pin connector from the radio, plug the connector into the female side of the T-harness from the 2760 interface. Plug the male 44 pin connector from the other end T-harness into the radio plug opening.



10. Run the other end of the harness from the 2760 to the screen opening. (Run the video rca's to behind the glove box or the driver side under dash depending on which side the camera wires are ran down.) Plug the harness into the 2760 interface box.
11. Reinstall the radio back into the dash.
12. Plug in the LCD harness into the 2760 interface box and secure the box down into the screen opening. (Be careful not to pinch and wiring)

## INSTALLATION INSTRUCTIONS

13. Connect the LCD harness from that was plugged into the screen to the to the blue connector marked car side.
14. Connect the other plug marked screen side to the back of the screen into the blue LCD plug.



15. Connect the other harness and reinstall the screen into the dash.
16. Connect the camera video rca to the yellow rca of the 2760.
17. Connect power to camera per camera magnifications instructions.
18. Reverse instructions to reassemble.
19. After reassembly turn on ignition, put vehicle in reverse and test for camera.

20. This installation was done in a 2013 GMC Terrain as a guide on which connectors have to be plug in and where they should run to. Other vehicles may be different but the connections will be the same.

**Note the LCD connectors will be done behind the screen on all installs.**