

**Ultrasonic Rear Park Aid
Truck extended length harness
(Kit # 9002-3001)**

Please read thoroughly before starting installation and check that kit contents are complete.

Items Included in the Kit:

Truck Wiring Harnesses
These Instructions

The Brandmotion Rear Park Aid (RPA) is designed to be a convenience aid to assist in backing your vehicle towards other vehicles and obstacles. It is not a safety system. Normal visual vigilance while backing is still recommended.

Safety Precautions:

- Work in well ventilated area that is clear of obstructions.
- Secure vehicle with tire chucks in both front and rear of tires.
- Turn vehicle accessories OFF and ensure ignition key is in OFF position.
- Wear safety goggles and snug fitting clothes.
- Use tools only for their intended purpose and which are in good repair.
- Only perform this task if confidence, skill, and physical ability permit.

NOTE: We strive to provide accurate and up-to-date installation instructions.

IMPORTANT: The Brandmotion Rear Park Aid (RPA) is designed to be a convenience aid to assist in backing your vehicle towards other vehicles and obstacles. It is not a safety system. Normal visual vigilance while backing is still recommended.

- 1.** Use this 1 harness for the 4 rear sensors instead of 4 sensors harness that came with the **9002-3000**. Install the metal the plugs with threaded end locks into the sensors, the white plastic connectors plug into the ECU.