

GM Wireless Charger Retrofit (Kit # FDMC-1275)

Please read thoroughly before starting installation and check that kit contents are complete.

Items Included in the Kit:

Wireless Charging Module
Spacers (optional installation)
These instructions

Tools & Supplies Needed:

Plastic panel removal tools
Digital Volt Meter / BCM safe test light
Screwdriver
Socket set
Wrench

Safety Precautions:

- Work in well ventilated area that is clear of obstructions.
- Secure vehicle with tire chucks in both front and rear of tires.
- Turn vehicle accessories OFF and ensure ignition key is in OFF position.
- Wear safety goggles and snug fitting clothes.
- Use tools only for their intended purpose and which are in good repair.
- Only perform this task if confidence, skill, and physical ability permit.

NOTE: We strive to provide accurate and up-to-date installation instructions. For the latest full color instructions, as well as an installation video, please visit www.brandmotion.com

1. Using a panel removal tool, separate the interior trim from the arm rest



2. Disconnect power harness from charging module



3. Locate 4 screws securing charging module and remove module. Save screws for next step.



4. Orient the replacement charging coil so that it is facing the mat on the top edge. Use saved screws to secure replacement module to armrest. (Add optional spacers to offset coil) Check from the top side of the armrest to see if the new plate needs to be spaced lower ie... coil is pushing up into rubber mat.



5. Connect power harness to new replacement charging module and snap panel back in place.

